




How to install driver Manometer on Windows 8

Before installing the driver Manometer for LEO5 from KELLER you have to deactivate the digital driver signature in Windows 8. These steps has to be done only once at installation.

First, press the “windows” button on your keyboard + “i” to launch the charm bar, and click “Change PC settings” at the bottom.


Then, go to “General”, and scroll to the bottom of the page, click “Restart now” button under “Advanced startup” section. **Remember to save all your work first before clicking it**




Note that on Windows 8.1, the Advanced startup option has moved to Update and recovery section under Recovery.



The computer reboots to a startup menu, in which click “Troubleshoot”.




And click “Advanced options” at next screen.






Choose “Startup Settings” next,




and click “Restart” button.





The computer reboots and prompts another menu to choose. One of the items is to disable driver signature enforcement. Press number “7” or “F7” to continue booting to Windows 8 with digital sign enforcement disabled.



Make sure the driver you are about to install is safe, though not digitally signed.

